



15 SPARK DELAY VALVE
INSTALL BLACK SIDE TOWARD
CARB

90° MOLDED END

- 1 Hose—dist. vacuum (yellow) 12"
- 2 Hose—dist. vacuum (black) 15"
- 3 Hose—dist. vacuum (green) 8"
- 4 Hose—dist. vacuum (red) 3"
- 5 Hose—dist. vacuum (red) 8"
- 6 Hose—dist. vacuum (red) 22"
- 7 Tee—3 way
- 8 Valve assy.—dist. vacuum control
- 9 Clip—wiring
- 10 Fitting—int. min vac. outlet
- 11 Solenoid—dist. vacuum
- 12 Stud & washer assy. 1/4-20-1/4-20 x 1.55
- 13 Nut & L/wash assy. 1/4-20
- 14 Hose—dist. vacuum (green) 2"
- 15 Spark delay valve
- 16 Hose—dist. vacuum (blue) 8"
- 17 Tee—3 way