

- 1 Hose—distributor vacuum (blue) 10"
- 2 Tee—3 way
- 3 Hose—distributor vacuum (blue) 18"
- 4 Fitting—intake manifold vacuum outlet (rear)
- 5 Hose—distributor vacuum (green) 9"
- 6 Hose—distributor vacuum (red) 9"
- 7 Hose—distributor vacuum (red) 2"
- 8 Hose—distributor vacuum (red) 7"
- 9 Hose—distributor vacuum (yellow) 28"
- 10 Hose—distributor vacuum (black) 22"
- 11 Hose—distributor vacuum (blue) 8"
- 12 Hose—distributor vacuum (red) 5"
- 13 Hose—distributor vacuum (red) 3"
- 14 Tee—4 way
- 15 Valve & brkt. assy.—dist. vac. advance control
- 16 Clip—wiring
- 17 Fitting—intake manifold vacuum outlet (front)
- 18 Tee—3 way
- 19 Valve assy.—dist. vac. control
- 20 Clip—wiring

