

C5GF-12127-A (1965-66 289 4V)

CENTRIFUGAL ADVANCE: Set the test stand to 0° at 250 rpm and 0 inches of mercury.

Distributor (rpm)	Advance (Degrees)	Vacuum (Inches of Mercury)
550	1½ - 2¼	0
700	5-6	0
1000	6¾ - 7¾	0
1400	7½ - 8¼	0
2000	8½ - 10	0

Maximum Advance Limit 14°

VACUUM ADVANCE: Set the test stand to 0° at 1000 rpm and 0 inches of mercury.

Distributor (rpm)	Advance (Degrees)	Vacuum (Inches of Mercury)
1000	1½ - 4½	8
1000	3½ - 6¾	10
1000	6¾ - 9¾	14
1000	8-11	20

Maximum Advance Limit 11°